

## Technical Details

- Dimensions: 149 x 96.5 x 85.5mm
- Ports: G1/4"
- Mounts: 2x 5mm LED

## Box Contents

- 1x Acrylic bay reservoir
- 1x Plastic mounting plate with o-ring
- 2x Aluminium faceplates with 4 screws
- 1x Allen Key
- 1x 5mm blue LED
- 4x M3 screws, 4x M4 screws
- G1/4" fittings sold separately*



1. Disassemble the D5 pump by unscrewing the circular bracket anticlockwise. Put the bracket, o-ring and pump front to one side, they're not needed.



2. Push the plastic mounting plate over the back of the pump. The circular cut-out on the plastic should be facing the front. Now place the new o-ring in the cut-out and around the pump.



3. Turn the pump over and put one of the M4 screws into each of the holes on the mounting plate. Make sure the o-ring stays in place



4. Lift the pump through the bottom of the reservoir and line up the 4 screw holes. Now take a screw driver and tighten each screw through the holes on the reservoirs side. Check the o-ring is compressed.



5. Use an adjustable spanner to connect the G1/4" fittings of your choice to the inlet and outlet. The reservoir is now ready to be connected to your other components and leak tested.



6. Choose a faceplate for the front of the reservoir and use the 4 allen head screws and the allen key tool to attach it.

## Filling and removing air

The filler cap can easily be removed by using a small coin and turning anti-clockwise. The reservoir should be filled before the pump is started to avoid damage.